

Semiconductor Manufacturing Technology

Michael Quirk & Julian Serda
© October 2001 by Prentice Hall

Chapter 8

Gas Control in Process Chambers

Objectives

After studying the material in this chapter, you will be able to:

1. Explain why process chambers are used in semiconductor manufacturing.
2. Describe the benefits of vacuum, the vacuum ranges and appropriate pumps.
3. Explain the need for gas flow in process chambers and how it is controlled.
4. Explain what is an RGA and why it is beneficial in process chambers.
5. Describe what is a plasma and how it is obtained.
6. Discuss the effects of contamination in chambers and how to minimize it.

The Many Functions of Process Chambers

- Controlling how gas **chemicals** flow into and react in the chamber in close proximity to the wafer.
- Creating a **vacuum** environment.
- **Removing** undesirable moisture, air and reaction by-products.
- Creating an environment for chemical reactions such as **plasma** to occur.
- Controlling the **heating and cooling** of the wafer.

Early 1960s Vacuum Bell Jar

- Many fabrication processes involves chemical reactions that take place in process chamber.
- Exposure to moisture, the ambient environment, and contaminants.
- In the beginning, only **2 steps** require a vacuum, one is evaporation of Al for contact and Au on back to package.





Figure 8.1

Integrated Cluster Tool

- The **multiple process** chambers are clustered around a central transfer chamber with a robot arm.
- Wafers are transported from process chamber to process chamber **under vacuum**, eliminating native oxide, reducing contamination.
- Increasing **throughput**.



Used with permission from Applied Materials, Inc., Endura PECVD system

Figure 8.2

Vacuum

- A **vacuum** exists when there is less pressure in an enclosed volume than in the surrounding **atmospheric pressure**.
- Benefits of Vacuum
- Vacuum Ranges
- Mean Free Path

Benefits of Vacuum in Semiconductor Manufacturing

Vacuum Condition	Benefit
1. Create clean environment	Particles, unwanted gases, moisture and contaminants are removed by a vacuum pump.
2. Low molecular density	Reduce the number of molecules in the system to reduce contamination and to move a gas out of the way (lower molecular interference).
3. Extend distance between collisions of molecules (Mean Free Path)	Necessary condition for creating the plasma needed in semiconductor processes such as sputtering and etch .
4. Accelerate reactions	Vacuum helps accelerate processes by lowering the vapor pressure of materials, so they can react faster with other chemicals.
5. Create a force	Vacuum creates a force, such as a vacuum pick-up on a robot arm.

Table 8.1

Vacuum Ranges

- The vacuum of deep space is about 10^{-16} torr.

Wafer Fab Processes	Vacuum Ranges in Torr				Chapter in book
	Rough $759 - 10^0$	Medium $10^0 - 10^{-3}$	High $10^{-3} - 10^{-6}$	Ultra High $10^{-6} - 10^{-9}$	
Oxidation					10
Photo					13 - 15
Polish					18
Etch					16
Deposition					11
Metallization					12
Ion Implant					17
Metrology					7

Table 8.2

Mean Free Path and Molecular Density Versus Pressure

MFP: the average distance a gas molecule moves before it strikes another molecule

	760 Torr (atmosphere)	1×10^{-3} Torr	1×10^{-9} Torr
# of molecules/cm³	3×10^{19} (30 million trillion)	4×10^{13} (40 trillion)	4×10^7 (40 million)


	760 Torr (atmosphere)	1×10^{-3} Torr	1×10^{-9} Torr
Mean free path	2×10^{-6} in	2-in	30 miles

Table 8.3

Vacuum Pumps

- Roughing Pump
 - Dry Mechanical Pump
 - Blower/Booster Pump
- High Vacuum Pump
 - Turbomolecular Pump
 - Cryopump
- Vacuum in Integrated Tools


Roughing Pump Exhausting a High Vacuum Pump



- remove **99.99%** of the initial air or contaminants
- $\sim 10^{-3}$ torr

Figure 8.3

Rotary Claw Dry Mechanical Pump



- $10^{-3} \sim 10^{-9}$ torr
- Use **nonmetal** materials on the moving surface to avoid the use of **oil** sealing or **lubricants**

Used with permission from International SEMATECH

Figure 8.4

Roots Blower Pump






Figure 8.5

Turbo Pump Blades




- $\sim 10^{-10}$ torr
- Like jet engine
- This pump gives a fast start-up to full pumping action once turn on
- Principle: **mechanical** compress
- **90,000 RPM**, to a roughing pump
- Same as roots, it cannot pump with viscous flow at atmosphere pressure
- High gas throughput
- 10-40 stator/rotor

Cryopump Compressor and Pump Module

- Making gas **cold** that they are **frozen** and **captured** in the chamber
- With no oils or moving parts, common used

Inlet to process chamber




Used with permission from Varian Vacuum Systems

Figure 8.7

Cryoarray Surfaces in Pump Module

- Cryopumps require a roughing pump and to remove the air from the pump and vacuum system
- These captured gases are removed periodically called **regeneration**, where pump is **warmed** and gases are **vent**



Used with permission from Varian Vacuum Systems

Figure 8.8

Cluster Tool Layout with Vacuum Environment

- Loadlock is where wafers enter the cluster tool, isolating the inner regions of the tool from the workplace environment
- Provide a well controlled, and low contamination environment




Figure 8.9


Process Chamber Gas Flow

The basic process chamber requirements for gas flow are:*

- Ability to handle a wide variety of bulk and specialty gases, many of which are corrosive and toxic.
- The control of gas flow into the process chamber is accurate and repeatable.
- The gas mix proportions are able to be controlled during the process run.
- Materials used in the chamber are not affected by the process gases and do not introduce contaminants into the gas stream.
- Common unit: standard cubic centimeters per minute (**sccm**) or standard liters per minute (**slm**)

Thermal Mass Flow Controller [MFC]

- **Idea gas law:** the number of gas molecules in a given volume changes in proportion to the absolute pressure and temperature
- Thus, controlling gas only by volume will not always yield the same number of gas molecules, which is undesirable for controlling chemical reactions
- MFC employs a heat-transfer property of the gas to directly measure the mass flow ratio into the chamber.



Mass Flow Controller



(Photo courtesy of MKS Instruments, Inc.)

Basic Parts of Residual Gas Analyzer (RGA)

- Used for **leak detection**, analysis of contamination, and as a **troubleshooting** tool




Figure 8.11

Quadrupole Mass Filter

- It consists of four cylindrical rods that have both a constant DC potential and a **high-frequency RF component**
- For a given voltage level applied to the cylinders, only ions of a given atomic **mass-to-charge** pass through the filter




Figure 8.12

RGA Measurement of a Process Chamber

- **Real time** information about cleanliness and stability of the process chamber during pump down.
- **Diagnosis** of process problems





Figure 8.13

Plasma

- **Plasma** is a neutral, highly energized, ionized gas consisting of neutral atoms or molecules, positive ions, and free electrons
- **Ionization** of gas atoms in a confined process chamber can occur by strong DC or AC electromagnetic **fields** or by **bombarding** the gas atoms with sort of electron source.
- Creation of an Ion (**Ionization**)
- Glow Discharge (**Excitation and Relaxation**)
- Radicals (**Dissociation**)
- RF Energy


Creation of an Ion

A neutral particle is an atom with an equal number of protons (+9) and electrons (-9).



Fluorine atom has a total of 7 valence electrons.

An ion is an atom with an unequal number of protons (+) and electrons (-).



Fluorine atom with one less electron.



Plasma Glow Discharge

- The most common indication that a plasma exists in a process chamber is the characteristic observable **light referred to as a glow discharge**




Figure 8.15

Electrically Exciting and Relaxing an Atom

- Life time of excited electron $\sim 10^{-9}$ sec
- Typical parameters **sustaining a glow discharge** include the RF power and frequency, pressure, gas mixture and flow rate, vacuum pumping speed and surface temperature




Figure 8.16

Dissociation of a Molecule





Figure 8.17

Typical Plasma Electrode Configuration

RF: 13.56 MHz,
Microwave: 2.45 GHz

- Electrons in the glow discharge can move **faster** toward the positive electrode when compared to slow moving massive positive ions
- **Dark space:** lack of electron
- **Positive** ion accelerates toward electrode → second e → maintain the glow discharge



Used with permission from International SEMATECH

Figure 8.18

Process Chamber Contamination

Recommendations to Minimize Contamination during Equipment Servicing	
1.	Maintain good temperature and humidity control in the cleanroom environment where the equipment is located.
2.	Control the equipment's pump and vent cycles to minimize turbulence and prevent particle generation when processing wafers.
3.	Avoid abrasive cleaning materials.
4.	Use exact replacement parts and materials to avoid subtle sources of equipment contamination.
5.	Use low particle-generating gas-handling components, such as regulators and automatic valves that have a tendency to generate particles.